



BL3080 MG Pro ECP - PUSH LEFT HAND



Keypad Side of Gate
Hinged on the **Left**
Opens towards you when opening

Push Pad Side of Gate
Hinged on the **Right**
Opens away from you when opening


BL3080 MG Pro ECP - PUSH RIGHT HAND



Keypad Side of Gate
Hinged on the **Right**
Opens towards you when opening

Push Pad Side of Gate
Hinged on the **Left**
Opens away from you when opening


BL3080 MG Pro ECP - PULL LEFT HAND



Keypad Side of Gate
Hinged on the **Left**
Opens away from you when opening

Pull Pad Side of Gate
Hinged on the **Right**
Opens towards you when opening

BL3080 MG Pro ECP - PULL RIGHT HAND



Keypad Side of Gate
Hinged on the **Right**
Opens away from you when opening

Pull Pad Side of Gate
Hinged on the **Left**
Opens towards you when opening