



## BL3030 MG Pro ECP - PUSH LEFT HAND



**Keypad Side of Gate**  
Hinged on the **Left**  
Opens towards you when opening

**Internal Keypad Side of Gate**  
Hinged on the **Right**  
Opens away from you when opening


## BL3030 MG Pro ECP - PUSH RIGHT HAND



**Keypad Side of Gate**  
Hinged on the **Right**  
Opens towards you when opening

**Internal Keypad Side of Gate**  
Hinged on the **Left**  
Opens away from you when opening


## BL3030 MG Pro ECP - PULL LEFT HAND



**Keypad Side of Gate**  
Hinged on the **Left**  
Opens away from you when opening

**Internal Keypad Side of Gate**  
Hinged on the **Right**  
Opens towards you when opening

## BL3030 MG Pro ECP - PULL RIGHT HAND



**Keypad Side of Gate**  
Hinged on the **Right**  
Opens away from you when opening

**Internal Keypad Side of Gate**  
Hinged on the **Left**  
Opens towards you when opening